



DX-2G Camera Language Setup Instructions

You will need the following items to proceed:

DX-2G Camera
Fully charged Battery

1. Remove DX-2G Lens Cap
2. Set Camera MODE to Auto (Green Camera Icon)
3. Turn Power On
4. Set Date and Time, if prompted
5. Press MENU button one time
6. Press RIGHT Arrow button one time to enter SETUP
7. Scroll up to setup screen #5 by pressing UP Arrow button 2 times until LANGUAGE function is highlighted
8. Press RIGHT Arrow button one time
9. Press DOWN Arrow button one time to select ENGLISH
10. Depress the "OK/Menu" Button to lock in setting
11. Proceed with normal use



Menu and Arrow Buttons



Power and Mode Dial



Step 5 Screenshot



Step 6 Screenshot



Step 7 Screenshot



Step 9 Screenshot